

SHAFT EXTRACTOR



DESCRIPTION


- The ACS Shaft Extractor is designed for use at the slitter/rewinder to position cores onto a shaft used to rewind slit paper, film, or other nonwoven materials from parent rolls then extract the shaft once the slitting cycle is complete.
- Design can be customized to accommodate shafts of varying diameter and lengths.
- Shafts are supported during extraction and reinsertion by a pneumatic pop-up support roller designed for easy setup to accommodate multiple shaft diameters.
- The ACS Shaft Extractor can be operated manually or integrated into existing system controls. A control console is provided for manual operation and selection of automatic mode of control.

FEATURES

- Reliable 2 HP gear motor with drive fully enclosed yet positioned for ease of access.
- Utilizes fiber optics and magnetic proximity sensors for precise control during extraction and insertion cycles.
- All pneumatics factory plumbed.
- Safety guards / access panels provide convenient access to machine components.
- Made with precision CNC plasma cut and punched components.



SHAFT EXTRACTOR



SPECIFICATIONS

Compatible Shaft Diameters: Original design accommodates 3" (7.62cm), 6" (15.24cm), and 6-3/4"

(17.145cm) shaft diameter. For other diameters, call factory.

Compatible Shaft Lengths: For shafts varying in length up to 208" (582.32cm). For other lengths, call

factory.

Pulling Head Speed: 89 FPM (27.13 MPM). For other speeds, call factory.

Drive Components:

Gear Motor: 2HP hollow shaft right angle gear motor. 230V/460V/3PH/60Hz. Other voltages

available as needed.

Pneumatics:

Minimum Air Requirements: 60 PSI (4.14 BAR) Clean, dry plant air at the drops.

Maximum Air Requirements: 80 PSI (5.52 BAR)

Construction:

Base Frame: Constructed using 3/16" (4.76mm) wall tubing.

Extractor Table: Constructed using 1/4" (6.35mm), 3/8" (9.525mm), and 1/2" (12.7mm) steel plate

and 1/4" (6.35mm) wall tubing.

Control Options:

Manual: Push button operator actuation from on-board control console.

Automatic: Automatic mode selection from on-board operator console.

